

PR-P05, 09

Контроллер

+12B	1
GND	2
W0/SIG	3
W1/SIG	4
LED-G/SIG	5
LED-R	6
Beep/ADR	7
Secure	8

