

PR-P05, 09

Контроллер

+12B	1
GND	2
W0/SIG	3
W1/SIG	4
LED-G/SIG	5
LED-R	6
Beep/ADR	7
Secure	8

Reader 1

1	+12B
2	Data 1
3	Data 2
1	LED
2	Beeper
3	GND

Reader 2

1	+12B
2	Data 1
3	Data 2
1	LED
2	Beeper
3	GND

